



INSTRUCTIONS FOR APPLYING SELF ADHESIVE PRODUCTS

Recommended for Indoor Use Only

The following is a general recommendation on the steps that can be taken to apply the Dixie® SmartStock® SKINS. Many of the points highlighted have been proven to supply trouble free performance after the application is undertaken.*

TEMPERATURE

The SmartStock® dispenser door and surrounding atmosphere should be 50°F or above for best results. If applications are to be made under 50°F, the dispenser door should be cleaned with isopropyl alcohol to insure good initial adhesion.

APPLICATION

- Materials:
1. Sponge
 2. Cold water in a bucket
 3. Clean cloth
 4. Pin or needle

1. Lay the dispenser flat.
2. Clean and dry the SmartStock® dispenser door.
(For more detailed instructions, See CLEANING.)
3. With the Dixie® SmartStock® SKIN face down, remove the backing paper slowly.
4. Use a sponge; flood the dispenser door and adhesive side of the decal with water.
5. Position the SKIN and use a clean cloth to press flat from top to bottom with light, overlapping strokes from the center outward toward each edge.
6. Dry the entire area with a clean cloth and press the SKIN with firm strokes, working away from the center outward toward each edge.
7. Allow to dry for twenty-four (24) hours and press firmly with a clean cloth.
8. If air bubbles occur, puncture with a pin or needle and smooth down.
9. If air bubbles are not removed completely, adhesive will turn white from air entrapment.

(Ultimate adhesion will occur 24 - 48 hour after application)

REMOVAL

The Dixie® SmartStock® SKIN can be removed by inserting a sharp knife or razor under a corner of the SKIN and peeling the film very carefully. The SKIN may not peel completely, but should remove in fairly decent size strips. Any residual adhesive that might transfer to the application surface can be removed by picking with the pressure-sensitive side of the removed SKIN. If this proves unsuccessful, a mild solvent may be used.

CLEANING

In general, the first step in application is to remove any grease, wax, oily substance, oil and/or dirt before applying the Dixie® SmartStock® SKIN. Normal dirt may be removed with a standard commercial detergent solution or mild soap. Oil, grease, or oil substances should be removed completely. After cleaning the SmartStock® dispenser door should then be rinsed with clean, warm water and dried with a clean, lint free cloth.

Experience has proven the Dixie® SmartStock® SKINS to be durable and lasting when applied to properly prepared SmartStock® dispenser doors.



Experience better.™